





# Pressure drawdown and sand production




500 psi slow drawdown

~ 60° breakouts




# Preventing sand production by limiting production rate




© Cambridge University Press Zoback, *Reservoir Geomechanics* (Fig. 10.23, pp. 336)

# Preventing sand production with perforation orientation




© Cambridge University Press Zoback, *Reservoir Geomechanics* (Fig. 10.24a, pp. 337)



© Cambridge University Press Zoback, *Reservoir Geomechanics* (Fig. 10.25, pp. 338)

# Preventing sand production with azimuth changes

## Considering fixed horizontal perforations



© Cambridge University Press Zoback, *Reservoir Geomechanics* (Fig. 10.24b, pp. 337)